


How to Siphon the Water and use the Handwashing Station.

1. Fill the top bucket with water up to the brim.
2. Close the loose end of the hose tightly with your thumb. Make sure no air can pass through when you close it.
3. Then drop the other end of the hose that is connected to the thin metal hook.
4. Lower the hose and open your thumb. This will create a sudden water pressure that will push the water to flow.
5. Once the flow works, insert the loose end of the hose into the middle hole found on the slider.
6. Then press the pedal and to lower the hose level which allows the flow of water.



PRECAUTIONARY MEASURES

1. Always situate your Unit in a more stable and flat surface area to avoid it to topple down.
2. Beware of getting clipped when you open the handwashing station.
3. Never use your mouth when you Siphon.
4. Don't let kids climb into the unit.
5. This Product is not for drinking purposes.

